



1. 300mm from corner of guard scuttle and bonnet. (corner to indicated red line)
2. Patch is NOT straight across scuttle, it flares out 25mm per side.
3. Patch starts 215mm in from corner of bonnet and scuttle. (Guard)
4. Follow angle of bonnet step, patch is NOT straight across.